

Recommended Heavy Vault Movement

When moving vaults of the size 24x36x24 and up it is recommended that the rope, strap/ lifting material is used as the video attached shows. In the video you can see the strap is just under the ring of the box and not directly on the bolts. The strap can be tied around the lifting bolts for extra security, but you would want to primarily lift the vault by putting the pressure/acting force on the ring. Please make sure you don't lift these vaults purely from the bolt and use all the available contact area to maximize the spread of the weight.

The video only shows the best placement for the lifting material. If there is any damage to these vaults, please provide a picture before or immediately after unloading the carrier. Following these instructions will provide the best results and minimize the risk of damaged to said vaults.

Thank you,

J&H American Enclosures Team.